

# TECHNOLOGY

Tecnología  
Technologie  
Technologie  
Tecnologia  
Tecnologia





### PLEX 4148

Teléfono. Conexión Jack 3,5 mm.  
 Telephone. 3,5 mm Jack Socket.  
 Téléphone. Connexion Jack 3,5 mm.  
 Telefon. 3,5 mm Klinkenstecker.  
 Telefono. Connessione Jack 3,5 mm.  
 Telefone. Conexão Jack 3,5 mm.

4,5 x 14,8 x 4,5 cm 100 / 50  
 Print Code: F(1)



### FONKI 4099

Bolígrafo Puntero. Carga Jumbo.  
 Stylus Touch Ball Pen. Jumbo Refill.  
 Stylet Bille. Recharge Jumbo.  
 Kugelschreiber Pointer. Jumbo Ersatzmine.  
 Penna Puntatore Touch. Refill Jumbo.  
 Esferográfica Punteiro. Carga Jumbo.

1,2 cm 13,7 cm 1000 / 50  
 Print Code: A(4)



19

TOUCH PEN



**JAKE 4105**

Puntero Limpiapantallas. Paño Limpiador Incluido.

Laser Pointer Screen Cleaner. Cleaner Cloth Included.

Stylét Nettoyer. Incluse Chiffonnette Nettoyant.

Touchpen Displayreiner. Putztuch Inklusive.

Puntatore Puliscischermo. Panno Incluso.

Ponteiro Limpador Ecrã. Inclui Pano Limpeza .

1 cm 10,5 cm 1000 / 50  
 Print Code: B(4)



**TYRSO 4162**

Puntero Laser. Pilas Botón Incluidas.  
 Laser Pointer. Button Batteries Included.  
 Pointeur Laser. Piles Bouton Incluses.  
 Laser Pointer. Knopfzellen Inklusive.  
 Puntatore Laser. Pile Bottone Incluse.  
 Ponteiro Laser. Pilhas Botão Incluídas.

1 cm 9,8 cm 1000 / 50  
 Print Code: E(1)



**GAZOR 4076**

Puntero Laser. Aluminio. Pilas Botón Incluidas.  
 Laser Pointer. Aluminium. Button Batteries Included.  
 Pointeur Laser. Aluminium. Piles Bouton Incluses.  
 Laser Pointer. Aluminium. Knopfzellen Inklusive.  
 Puntatore Laser. Alluminio. Pile Bottone Incluse.  
 Ponteiro Laser. Alumínio. Pilhas Botão Incluídas.

1 cm 12 cm 500 / 50  
 Print Code: D(4)





## TOUCH PEN



## LEVAC 4106




Boligrafo Puntero.  
Stylus Touch Ball Pen.  
Stylet Bille.  
Kugelschreiber Pointer.  
Penna Puntatore Touch.  
Esferográfica Ponteiro.

 ø 0,9 cm 13,5 cm  1000 / 50  
   Print Code: B(4)



## KODY 4175

Boligrafo Puntero.  
Stylus Touch Ball Pen.  
Stylet Bille.  
Kugelschreiber Pointer.  
Penna Puntatore Touch.  
Esferográfica Ponteiro.


 ø 1,1 cm 13,5 cm  1000 / 50  
   Print Code: B(4)



## SUKI 4102

Boligrafo Puntero. Escritura 4 Colores.  
Stylus Touch Ball Pen. 4 Colours Ink.  
Stylet Bille. Écriture 4 Couleurs.  
Kugelschreiber Pointer. 4 Farben Schreiben.  
Penna Puntatore Touch. Inchiostro 4 Colori.  
Esferográfica Ponteiro. Escrita 4 Cores.

 ø 1,2 cm 14 cm  1000 / 50  
    Print Code: B(4)



## TECXO 4125

Boligrafo Puntero. Aluminio. Carga Jumbo.  
Stylus Touch Ball Pen. Aluminium. Jumbo Refill.  
Stylet Bille. Aluminium. Recharge Jumbo.  
Kugelschreiber Pointer. Aluminium. Jumbo Ersatzmine.

Penna Puntatore Touch. Aluminio. Refill Jumbo.  
Esferográfica Ponteiro. Alumínio. Carga Jumbo.

 ø 1 cm 14 cm  500 / 50  
   Print Code: B(4), L



TOUCH PEN



LYPTUS 4107

Puntero Limpiapantallas.  
Pointer Screen Cleaner.  
Stylét Nettoyer.  
Touchpen Displayreiner.  
Puntatore Puliscischermo.  
Ponteiro Limpador Ecrã.

6 x 3 x 1 cm 1000 / 200  
Print Code: D(4)



FION 4006

Puntero.  
Stylus Touch Pen.  
Stylét.  
Touchpad Stift.  
Puntatore Touch.  
Ponteiro.

ø 1 cm 12 cm 1000 / 50  
Print Code: A(4)



TAP 3690

Puntero. Aluminium.  
Stylus Touch Pen. Aluminium.  
Stylét. Aluminium.  
Touchpad Stift. Aluminium.  
Puntatore Touch. Alluminium.  
Ponteiro. Aluminium.

ø 0,8 cm 11,2 cm 1000 / 100  
Print Code: B(4), L



## TOUCH PEN

## INDUR 4036

Puntero Llavoro.  
Stylus Touch Pen Keyring.  
Styllet Porte-Clés.  
Touchpen Schlüsselanhänger.  
Puntatore Touch Portachiavi.  
Ponteiro Porta-Chaves.

 ø 0,9 cm 4,8 cm  1000 / 50  
 Print Code: D(4)



## EOLO 4038




Puntero.  
Stylus Touch Pen.  
Styllet.  
Touchpad Stift.  
Puntatore Touch.  
Ponteiro.

 ø 0,8 cm 4,8 cm  2000 / 100  
 Print Code: C(4)



## SIRUX 3981

Puntero Llavoro. Aluminio.  
Stylus Touch Pen Keyring. Aluminium.  
Styllet Porte-Clés. Aluminium.  
Touchpen Schlüsselanhänger. Aluminium.  
Puntatore Touch Portachiavi. Aluminium.  
Ponteiro Porta-Chaves. Aluminium.

 ø 0,9 cm 5,5 cm  1000 / 100  
 Print Code: D(4), L



**MINOX 3960**

Bolígrafo Puntero. Aluminio.

Stylus Touch Ball Pen. Aluminium.


Stylét Bille. Aluminium.


Kugelschreiber Pointer. Aluminium.

Penna Puntatore Touch. Alluminio.

Esterográfica Ponteiro. Aluminio.

 0,9 cm 12,5 cm
  1000 / 50

 Print Code: B(4), L
**LATRO 4012**Bolígrafo Puntero. Aluminio. Linterna.  
3 Pilas Botón Incluidas.Stylus Touch Ball Pen. Aluminium. Torch.  
3 Button Batteries Included.Stylét Bille. Aluminium. Lampe. 3 Piles  
Bouton Incluses.Kugelschreiber Pointer. Aluminium. Lampe.  
3 Knopfzellen Inklusive.Penna Puntatore Touch. Alluminio. Torcia.  
3 Pile Bottone Inclusive.Esterográfica Ponteiro. Aluminio. Lanterna.  
3 Pilhas Botão Incluídas.
 1,2 cm 13 cm
  500 / 50

 Print Code: B(4)
**SILUM 3980**

Bolígrafo Puntero. Aluminio.



Stylus Touch Ball Pen. Aluminium.


Stylét Bille. Aluminium.

Kugelschreiber Pointer. Aluminium.

Penna Puntatore Touch. Alluminio.

Esterográfica Ponteiro. Aluminio.

 0,9 cm 11,2 cm
  1000 / 50

 Print Code: B(4), L


**TOUCH PEN**

■ ■ ■ ANTONIO MIRO ■ ■ ■

**YAGO 7160**

Bolígrafo Puntero. Metálico.  
 Stylus Touch Ball Pen. Metallic.  
 Stylet Bille. Métallique.  
 Kugelschreiber Pointer. Metallic.  
 Penna Puntatore Touch. Metallo.  
 Esferográfica Ponteiro. Metálico.

▣ ø 1 cm 14 cm    📦 200 / 100  
 🖨️ Print Code: D(1), L



**LEYTON 3919**

Bolígrafo Puntero.  
 Stylus Touch Ball Pen.  
 Stylet Bille.  
 Kugelschreiber Pointer.  
 Penna Puntatore Touch.  
 Esferográfica Ponteiro.

▣ ø 1,4 cm 14 cm    📦 1000 / 50  
 🖨️ Print Code: B(4)



**NISHA 4084**


Bolígrafo Puntero. Aluminio.  
 Stylus Touch Ball Pen. Aluminium.  
 Stylet Bille. Aluminium.  
 Kugelschreiber Pointer. Aluminium.  
 Penna Puntatore Touch. Alluminio.  
 Esferográfica Ponteiro. Alumínio.

▣ ø 0,9 cm 14 cm    📦 1000 / 50  
 🖨️ Print Code: B(4)



01

02





**TOUCH PEN**



**NOXI 4126**

Bolígrafo Puntero.  
Stylus Touch Ball Pen.  
Stylét Bille.  
Kugelschreiber Pointer.  
Penna Puntatore Touch.  
Esterográfica Ponteiro.

ø 1 cm 14 cm 1000 / 50  
 Print Code: A(4)



**KATON 4100**

Bolígrafo Puntero.  
Stylus Touch Ball Pen.  
Stylét Bille.  
Kugelschreiber Pointer.  
Penna Puntatore Touch.  
Esterográfica Ponteiro.

ø 1,1 cm 14 cm 1000 / 50  
 Print Code: A(4)



**MARLO 4011**

Bolígrafo Puntero.  
Stylus Touch Ball Pen.  
Stylét Bille.  
Kugelschreiber Pointer.  
Penna Puntatore Touch.  
Esterográfica Ponteiro.

ø 1,2 cm 13,5 cm 1000 / 50  
 Print Code: A(4)



**SAGUR 4037**

Bolígrafo Puntero.  
Stylus Touch Ball Pen.  
Stylét Bille.  
Kugelschreiber Pointer.  
Penna Puntatore Touch.  
Esterográfica Ponteiro.

ø 1 cm 13,5 cm 1000 / 50  
 Print Code: A(4)

**TOUCH PEN**



**SURY 4101**

Boligrafo Puntero.  
Stylus Touch Ball Pen.  
Stylet Bille.  
Kugelschreiber Pointer.  
Penna Puntatore Touch.  
Esferográfica Ponteiro.

ø 1,5 cm 13,5 cm 1000 / 50  
 Print Code: A(4)



**SARKO 4044**

Boligrafo Puntero. Carga Jumbo.  
Stylus Touch Ball Pen. Jumbo Refill.  
Stylet Bille. Recharge Jumbo.  
Kugelschreiber Pointer. Jumbo Ersatzmine.  
Penna Puntatore Touch. Refill Jumbo.  
Esferográfica Ponteiro. Carga Jumbo.

ø 1,2 cm 14 cm 1000 / 50  
 Print Code: A(4)



**ACTIUM 4010**

Guante Táctil. Acrílico. Talla Única.  
Touch Gloves. Acrylic. One size.  
Gant Tactile. Acrylique. Taille Unique.  
Touchpad Handschuhe. Acryl.  
Einheitsgröße.  
Guanti Tattile. Acrilico. Taglia Unica.  
Luvas Tátil. Acrílico. Tamanho Único.

200 / 10  
 Print Code: N(8)



Permanent Stock  
The best price  
1 Year Warranty

4  
GB

expressprinting48h

### FIXING 4GB 3560 4GB

Memoria USB. Aluminio. Presentación Individual.

USB Memory. Aluminium. Individual Presentation.

Clé USB. Aluminium. Présentation Individuelle.

USB Speicher. Aluminium. Individuelle Präsentation.

Chiavetta USB. Alluminio. Presentazione Individuale.

Memória USB. Aluminio. Apresentação Individual.


2,4 x 5,7 x 0,2 cm 200  
Print Code: D(4), L



11

03

07




09

19

01

02

04



### KEYTON 4GB 4193 4GB

Memoria USB. Aluminio. Presentación Individual.

USB Memory. Aluminium. Individual Presentation.

Clé USB. Aluminium. Présentation Individuelle.

USB Speicher. Aluminium. Individuelle Präsentation.

Chiavetta USB. Alluminio. Presentazione Individuale.

Memória USB. Aluminio. Apresentação Individual.

2,5 x 3,6 x 0,2 cm 200  
Print Code: D(4), L



09

23



### ASHTON 4GB 3654 4GB

Memoria USB. Presentación Individual.

USB Memory. Individual Presentation.

Clé USB. Présentation Individuelle.

USB Speicher. Individuelle Präsentation.

Chiavetta USB. Presentazione Individuale.

Memória USB. Apresentação Individual.

1,8 x 5,2 x 0,9 cm 250  
Print Code: L



02



01



19



03



**Permanent Stock**  
The best price  
1 Year Warranty

**4 GB**

**expressprinting48h**



**TOGU 4GB 3226 4GB**

Memoria USB. Presentación Individual.  
USB Memory. Individual Presentation.  
Clé USB. Présentation Individuelle.  
USB Speicher. Individuelle Präsentation.  
Chiavetta USB. Presentazione Individuale.  
Memória USB. Apresentação Individual.

1,8 x 5,7 x 0,9 cm 300  
Print Code: D(4), L



**NORDIX 4GB 3962 4GB**

Memoria USB. Presentación Individual.  
USB Memory. Individual Presentation.  
Clé USB. Présentation Individuelle.  
USB Speicher. Individuelle Präsentation.  
Chiavetta USB. Presentazione Individuale.  
Memória USB. Apresentação Individual.

1,9 x 5,6 x 1,4 cm 500  
Print Code: D(4)

The best price

**2 GB** **Permanent Stock**  
1 Year Warranty

**expressprinting48h**



**EKON 2GB 4191 2GB**

Memoria USB. Presentación Individual.  
USB Memory. Individual Presentation.  
Clé USB. Présentation Individuelle.  
USB Speicher. Individuelle Präsentation.  
Chiavetta USB. Presentazione Individuale.  
Memória USB. Apresentação Individual.

1,8 x 5,7 x 0,9 cm 300  
Print Code: D(4), L



Permanent Stock  
The best price  
1 Year Warranty

**4 GB**

**expressprinting48h**



**STYLUS 4GB 4194 4GB**

Memoria USB-Puntero. Presentación Individual.

USB Memory Stylus Touch. Individual Presentation.

Clé USB Stylet. Présentation Individuelle.

UBS Speicher Touchpad. Individuelle Präsentation.

Chiavetta USB Puntatore Touch. Presentazione Individuale.

Memória USB Ponteiro. Apresentação Individual.

1.9 x 7 x 0.8 cm 300

Print Code: D(4)



**AKOR 4GB 4065 4GB**

Memoria USB-Puntero. Metálico. Presentación Individual.

USB Memory Stylus Touch. Metallic. Individual Presentation.

Clé USB Stylet. Métallique. Présentation Individuelle.

UBS Speicher Touchpad. Metallic. Individuelle Präsentation.

Chiavetta USB Puntatore Touch. Metallo. Presentazione Individuale.

Memória USB Ponteiro. Metálico. Apresentação Individual.

1.2 x 5.5 x 0.8 cm 200 / 25

Print Code: D(4), L



**KROM 4GB 3655 4GB**

Memoria USB. Metálico. Presentación Individual.

USB Memory. Metallic. Individual Presentation.

Clé USB. Métallique. Présentation Individuelle.

USB Speicher. Metallic. Individuelle Präsentation.

Chiavetta USB. Metallo. Presentazione Individuale.

Memória USB. Metálico. Apresentação Individual.

2 x 5.2 x 0.7 cm 200

Print Code: L



**Permanent Stock**  
The best price  
1 Year Warranty

**4 GB**

**expressprinting48h**



**PUSH 4GB 4192 4GB**

Memoria USB. Presentación Individual.  
USB Memory. Individual Presentation.  
Clé USB. Présentation Individuelle.  
USB Speicher. Individuelle Präsentation.  
Chiavetta USB. Presentazione Individuale.  
Memória USB. Apresentação Individual.

2 x 5,8 x 1,1 cm 200  
Print Code: D(4)

**INTREX 4GB 3910 4GB**

Mini Memoria USB. Aluminio. Presentación Individual.  
Mini USB Memory. Aluminium. Presentation Individual.  
Mini Clé USB. Aluminium. Présentation Individuelle.  
Mini USB Speicher. Aluminium. Individuelle Präsentation.  
Mini Chaivetta USB. Alluminio. Presentazione Individuale.  
Mini-Memória USB. Alumínio. Apresentação Individual.

1,2 x 3,3 x 0,6 cm 1000 / 250  
Print Code: D(4), L



**TRAVIS 4GB 4195 4GB**

Boligrafo USB. Metálico. Presentación Individual.  
USB Pen. Metallic. Individual Presentation.  
Stylo USB. Métallique. Présentation Individuelle.  
Kugelschreiber USB. Metallisch. Individuelle Präsentation.  
Penna USB. Metallo. Presentazione Individuale.  
Esferegráfica USB. Metálico. Apresentação Individual.

∅ 1,4 cm 12,5 cm 100 / 20  
Print Code: D(4), E(1)



## ■■■ ANTONIO MIRO ■■■

## LATREX 8GB 7255 8GB

Boligrafo Puntero USB. Metálico.  
Presentación Individual.

Stylus Touch Ball Pen USB Memory.  
Metallic. Individual Presentation.

Stylét Bille Clé USB. Métallique.  
Présentation Individuelle.

Kugelschreiber Pointer USB. Metallisch.  
Individuelle Präsentation.

Penna Puntatore Touch USB. Metallo.  
Presentazione Individuale.

Esferegráfica Punteiro USB. Metálico.  
Apresentação Individual.

1.4 cm 13,8 cm 100  
Print Code: D(1)



## ■■■ ANTONIO MIRO ■■■

## MISON 8GB 7171 8GB

Memoria USB. Piel. Presentación Individual.

USB Memory. Leather. Individual  
Presentation.

Clé USB. Cuir. Présentation Individuelle.

USB Speicher. Leder. Individuelle  
Präsentation.

Chiavetta USB. Pelle. Presentazione  
Individuale.

Memória USB. Pele. Apresentação  
Individual.

2,3 x 6,8 x 1 cm 200  
Print Code: D(4), L



## ■■■ ANTONIO MIRO ■■■

## LIBER 4GB 7172 4GB

Memoria USB. Presentación Individual.

USB Memory. Individual Presentation.

Clé USB. Présentation Individuelle.

USB Speicher. Individuelle Präsentation.

Chiavetta USB. Presentazione Individuale.

Memória USB. Apresentação Individual.

2,1 x 5,3 x 0,9 cm 100  
Print Code: D(4)



# asiaexpress

TECHNOLOGY 29

*more than* **1000 different models** *special designs*



≥ 100



15 days



1Gb - 32Gb





03

02

### MIKA 3972

Lector Tarjetas. Tarjetas: M2, MS Duo, MicroSD, SD.

Card Reader. Cards: M2, MS Duo, MicroSD, SD.

Lecteur Cartes. Cartes : M2, MS Duo, MicroSD, SD.

Kartenleser. Karten: M2, MS Duo, MicroSD, SD.

Lettore Card. Carte: M2, MS Duo, MicroSD, SD.

Leitor Cartões. Cartões: M2, MS Duo, MicroSD, SD.

6 x 1,6 x 2,2 cm 500 / 100

Print Code: D(4)



19



05



03



01



02



19

### ARES 3509

Lector Tarjetas. USB 2.0. Tarjetas: M2, MS Duo, MicroSD, SD.

Card Reader. USB 2.0. Cards: M2, MS Duo, MicroSD, SD.

Lecteur Cartes. USB 2.0. Cartes : M2, MS Duo, MicroSD, SD.

Kartenleser. USB 2.0. Karten: M2, MS Duo, MicroSD, SD.

Lettore Card. USB 2.0. Carte: M2, MS Duo, MicroSD, SD.

Leitor Cartões. USB 2.0. Cartões: M2, MS Duo, MicroSD, SD.

5,7 x 1,5 x 4 cm 600 / 100

Print Code: F(4)



04

03

01

07

19



02

### DRO 3692

Lector Tarjetas. USB 2.0. Tarjetas MicroSD.

Card Reader. USB 2.0. MicroSD Cards.

Lecteur Cartes. USB 2.0. Cartes MicroSD.

Kartenleser. USB 2.0. MicroSD Karten.

Lettore Card. USB 2.0. Carte MicroSD.

Leitor Cartões. USB 2.0. Cartões MicroSD.

2 x 5 x 0,4 cm 1000 / 100

Print Code: D(4)



19

03

02

01

### APEK 3398

Lector Tarjetas. USB 2.0. Tarjetas MicroSD.

Card Reader. USB 2.0. MicroSD Cards.

Lecteur Cartes. USB 2.0. Cartes MicroSD.

Kartenleser. USB 2.0. MicroSD Karten.

Lettore Card. USB 2.0. Carte MicroSD.

Leitor Cartões. USB 2.0. Cartões MicroSD.

ø 3 cm 1000 / 100

Print Code: D(4)





01



03

## HADES 3383

Lector Tarjetas. USB 2.0. Tarjetas: M2, MS Duo, MS Pro Duo, MS, MS Pro, MicroSD, MiniSD, RS MMC, SD, MMC.

Card Reader. USB 2.0. Cards: M2, MS Duo, MS Pro Duo, MS, MS Pro, MicroSD, MiniSD, RS MMC, SD, MMC.

Lecteur Cartes. USB 2.0. Cartes: M2, MS Duo, MS Pro Duo, MS, MS Pro, MicroSD, MiniSD, RS MMC, SD, MMC.

Kartenleser. USB 2.0. Karten: M2, MS Duo, MS Pro Duo, MS, MS Pro, MicroSD, MiniSD, RS MMC, SD, MMC.

Lettore Card. USB 2.0. Carte: M2, MS Duo, MS Pro Duo, MS, MS Pro, MicroSD, MiniSD, RS MMC, SD, MMC.

Leitor Cartões. USB 2.0. Cartões: M2, MS Duo, MS Pro Duo, MS, MS Pro, MicroSD, MiniSD, RS MMC, SD, MMC.

6,5 x 1 x 2 cm 300 / 30  
 Print Code: F(4)



02



19



03

## DIRA 3693

Lector Tarjetas. USB 2.0. Tarjetas: MS, MS Duo, MS Pro Duo, MicroSD, MiniSD.

Card Reader. USB 2.0. Cards: MS, MS Duo, MS Pro Duo, Micro SD, MiniSD.

Lecteur Cartes. USB 2.0. Cartes MS, MS Duo, MS Pro Duo, MicroSD, MiniSD.

Kartenleser. USB 2.0. Karten: MS, MS Duo, MS Pro Duo, MicroSD, MiniSD.

Lettore Card. USB 2.0. Carte: MS, MS Duo, MS Pro Duo, Micro SD, MiniSD.

Leitor Cartões. USB 2.0. Cartões: MS, MS Duo, MS Pro Duo, MicroSD, MiniSD.

7,5 x 1,5 x 2,3 cm 500 / 100  
 Print Code: F(4)



05



19



02



19

## DIGIT 3475

Estuche Tarjetas. Aluminio. Tarjetas: SIM, SD, MiniSD.

Card Case. Aluminium. Cards: SIM, SD, MiniSD.

Etui Cartes. Aluminium. Cartes: SIM, SD, MiniSD.

Speicherkartenetui. Aluminium. Karten: SIM, SD, MiniSD.

Astuccio Carte. Alluminio. Carte: SIM, SD, MiniSD.

Estojo Porta-Cartões. Alumínio. Cartões: SIM, SD, MiniSD.

6 x 4,5 x 0,5 cm 800 / 50  
 Print Code: D(4)



09



03



### ELECTRON 3566

Lector Tarjetas. USB 2.0. Smart Card.  
 Card Reader. USB 2.0. Smart Card.  
 Lecteur Cartes. USB 2.0. Smart Card.  
 Kartenleser. USB 2.0. Smart Card.  
 Lettore Card. USB 2.0. Smart Card.  
 Leitor Cartões. USB 2.0. Smart Card.

8,2 x 1,5 x 6,5 cm 100 / 25  
 Print Code: D(4)



### SECURE 3565

Lector Tarjetas. USB 2.0. Tarjetas: MS, M2, SD, MiniSD, Smart Card, SIM, MicroSD.  
 Card Reader. USB 2.0. Cards: MS, M2, SD, MiniSD, Smart Card, SIM, MicroSD.  
 Lecteur Cartes. USB 2.0. Cartes: MS, M2, SD, MiniSD, Smart Card, SIM, MicroSD.  
 Kartenleser. USB 2.0. Karten: MS, M2, SD, MiniSD, Smart Card, SIM, MicroSD.  
 Lettore Card. USB 2.0. Carte: MS, M2, SD, MiniSD, Smart Card, SIM, MicroSD.  
 Leitor Cartões. USB 2.0. Cartões: MS, M2, SD, MiniSD, Smart Card, SIM, MicroSD.

8,1 x 1,3 x 3,1 cm 100 / 25  
 Print Code: D(4)



### USAK 3498

Lector Tarjetas. Tarjetas: SD, MiniSD, MMC, XD, MS, CF.  
 Card Reader. Cards: SD, MiniSD, MMC, XD, MS, CF.  
 Lecteur Cartes. Cartes: SD, MiniSD, MMC, XD, MS, CF.  
 Kartenleser. Karten: SD, MiniSD, MMC, XD, MS, CF.  
 Lettore Card. Carte: SD, MiniSD, MMC, XD, MS, CF.  
 Leitor Cartões. Cartões: SD, MiniSD, MMC, XD, MS, CF.

13 x 3 x 7,5 cm 60  
 Print Code: F(4)





## MERK 3432

Soporte Móvil. Conexión USB 2.0. Lector Tarjetas: SD, MicroSD/ TF, MS, M2.

Mobile Holder. USB 2.0. Card Reader: SD, MicroSD/ TF, MS, M2.

Support Mobile. Connection USB 2.0. Lecteur Cartes: SD, MicroSD/ TF, MS, M2.

Handyhalter. USB 2.0 Anschluss. Karten Reader: SD, MicroSD/ TF, MS, M2.

Supporto Cellulare. Connessione USB 2.0. Card: SD, MicroSD/ TF, MS, M2.

Soporte Telemóvil. Conexão USB 2.0. Leitor Cartões: SD, MicroSD/ TF, MS, M2.

6 x 10 x 11 cm 50  
 Print Code: F(4), L



## INUK 3686

Soporte Móvil. 2 Puertos. USB 2.0. Lector Tarjetas: SD, MicroSD/ TF, MS, M2.

Mobile Holder. 2 Hubs. USB 2.0. Card Reader: SD, MicroSD/ TF, MS, M2.

Support Mobile. 2 Ports. USB 2.0. Lecteur Cartes: SD, MicroSD/ TF, MS, M2.

Handyhalter. 2 Ports USB 2.0. Kartenleser: SD, MicroSD/ TF, MS, M2.

Supporto Cellulare. 2 Porte USB 2.0. Lettore Card: SD, MicroSD/ TF, MS, M2.

Soporte Telemóvil. 2 Portas. USB 2.0. Leitor de Cartões: SD, MicroSD/ TF, MS, M2.

6 x 9,6 x 9 cm 100  
 Print Code: F(4)



## CHAIR 9789

Soporte Móvil. 4 Puertos.

Mobile Holder. 4 Hubs.

Support Mobile. 4 Ports.

Handyhalter. 4 Ports.

Supporto Cellulare. 4 Porte.

Soporte Telemóvil. 4 Portas.

6,2 x 7,3 x 7,3 cm 100 / 50  
 Print Code: F(4)



## MUG 9528

Calentador Tazas. Conexión USB.

Cup Warmer. USB Connection.

Chauffe Tasses. Connexion USB.

Becher Wärmer. USB Anschluss.

Scaldatazza. Connessione USB.

Aquecedor Chávenas. Conexão USB.

ø 10 cm 2,1 cm 100  
 Print Code: F(4)



### POD 3899

Puerto USB. 3 Puertos. USB 2.0.

USB Hub. 3 Hubs. USB 2.0.

Port USB. 3 Ports. USB 2.0.


USB Hub. 3 Ports. USB 2.0.

Porta USB. 3 Porte. USB 2.0.

Porta USB. 3 Portas. USB 2.0.

▲ 3,5 cm 24 cm ▲ 200 / 50

▲▲▲ Print Code: F(4)



### GEBY 3385

Puerto USB. 4 Puertos. USB 2.0.

USB Hub. 4 Hubs. USB 2.0.

Port USB. 4 Ports. USB 2.0.

USB Hub. 4 Ports. USB 2.0.

Porta USB. 4 Porte. USB 2.0.

Porta USB. 4 Portas. USB 2.0.

▲ 5,5 x 2 x 2 cm ▲ 300 / 30

▲▲▲ Print Code: F(4)



### PROC 9523

Puerto USB. 4 Puertos.

USB Hub. 4 Hubs.

Port USB. 4 Ports.

USB Hub. 4 Ports.

Porta USB. 4 Porte.

Porta USB. 4 Portas.

▲ 14,5 x 1,7 x 3,5 cm ▲ 100 / 50

▲▲▲ Print Code: F(4)





### TISCO 3621

Lector Tarjetas Puerto USB. 3 Puertos. USB 2.0. Tarjetas: M2, MS Duo, MS Pro Duo, MS, MS Pro, MicroSD, MiniSD, RS MMC, SD, MMC.

Card Reader USB Hub. 3 Hubs. USB 2.0. Cards: M2, MS Duo, MS Pro Duo, MS, MS Pro, MicroSD, MiniSD, RS MMC, SD, MMC.

Lecteur Cartes Port USB. 3 Ports. USB 2.0. Cartes: M2, MS Duo, MS Pro Duo, MS, MS Pro, MicroSD, MiniSD, RS MMC, SD, MCC.

USB Hub Kartenleser. 3 Ports. USB 2.0. Karten: M2, MS Duo, MS Pro Duo, MS, MS Pro, MicroSD, MiniSD, RS MMC, SD, MMC.

Lettore Card Porta USB. 3 Porte. USB 2.0. Carte: M2, MS Duo, MS Pro Duo, MS, MS Pro, MicroSD, MiniSD, RS MMC, SD, MMC.

Leitor Cartões Porta USB. 3 Portas. USB 2.0. Cartões: M2, MS Duo, MS Pro Duo, MS, MS Pro, MicroSD, MiniSD, RS MMC, SD, MMC.

6,8 x 2 x 4 cm 200 / 50  
 Print Code: F(4)



03




02



19



01



### NICO 3428

Puerto USB. 4 Puertos. USB 2.0. Pilas Botón Incluidas.

USB Hub. 4 Hubs. USB 2.0. Button Batteries Included.

Port USB. 4 Ports. USB 2.0. Piles Bouton Incluses.

USB Hub. 4 Ports. USB 2.0. Knopfzellen Inklusive.

Porta USB. 4 Porte. USB 2.0. Pile Bottone Incluse.

Porta USB. 4 Portas USB 2.0. Pilhas Botão Incluídas.

9,5 x 2 x 4,5 cm 100 / 20  
 Print Code: F(4)



### OHM 3898

Puerto USB. 4 Puertos.

USB Hub. 4 Hubs.

Port USB. 4 Ports.

USB Hub. 4 Ports.

Porta USB. 4 Porte.

Porta USB. 4 Portas.

9,6 x 2 x 3 cm 200 / 50  
 Print Code: E(4)



03

01


19



### MITA 3540

Soporte. Adhesivo.  
Holder. Adhesive.  
Support. Adhésif.  
Halter. Haftend.  
Supporto. Adesivo.  
Suporte. Adesivo.

2,8 cm 1,6 cm 2000 / 200  
Print Code: E(1)



### AIRYS 8200

Antirrullo Teléfono.  
Phone Untangler.  
Anti Enrouleur.  
Telefon Entwirrer.  
Blocca Cavo Telefono.  
Anti-Enrolador.

1,5 x 4,7 x 1,2 cm 1000 / 100  
Print Code: C(4)



### CONFERENCE 3022

Webcam. Resolución 1.3 MP Interpolados.  
Incluye Cable USB y CD Instalación.

Webcam. 1.3 MP Interpolated Resolution.  
Cable and CD Installation Software  
Included.

Webcam. Résolution 1.3 MP. Inclus Câble  
USB et CD.

Webcam. 1.3MP Interpolierte Auflösung.  
Kabel und Installation CD Inklusive.

Webcam. Risoluzione 1.3 MP Interpolati.  
Cavo USB e CD Installazione Inclusive.

Webcam. Resolução 1.3 MP Interpolados.  
Inclui Cabo e CD Instalação.

2,3 x 6 x 5 cm 150 / 50  
Print Code: F(4)



### PRAMI 3490

Webcam USB. Metal. Resolución 1.3 MP.

USB Webcam. Metal. Resolution 1.3 MP.

Webcam USB. Métal. Résolution 1.3 MP.

USB Webcam. Metall. Auflösung 1.3 MP.

Webcam USB. Metalico. Risoluzione 1.3 MP.

Webcam USB. Metal. Resolução 1.3 MP.

0,5 cm 38 cm 200 / 50  
Print Code: F(4)





### SALVIA 4051

Estuche Informática. Soft Shell.  
 Computer Case. Soft Shell.  
 Housse d'Ordinateur. Soft Shell.  
 Computertasche. Soft Shell.  
 Astuccio Computer. Soft Shell.  
 Estojo Informática. Soft Shell.

17 x 13,5 x 1 cm 200 / 50  
 Print Code: E(1), N(6)



### ROUX 3971

Cable Datos Cargador. Extensible.  
 Conexiones MiniUSB, MicroUSB y  
 Dispositivos Apple.

Charger Data Cable. Retractable. MiniUSB,  
 MicroUSB and Apple Devices Connections.

Câble Informatique Chargeur. Extensible.  
 Connexions MiniUSB, MicroUSB et  
 Dispositifs Apple.

Datenkabel Ladegerät. Ausziehbar.  
 Anschlüsse MiniUSB, MicroUSB und Apple  
 Geräte.

Cavo Dati Caricatore. Estendibile.  
 Connessioni MiniUSB, MicroUSB e  
 Dispositivi Apple.

Cabo Dados Carregador. Extensível.  
 Conexões MiniUSB, MicroUSB e  
 Aparelhos Apple.

14 x 1,5 x 3 cm 400 / 100  
 Print Code: E(4)



### GLUC 3504

Cable Datos. Conexión RJ45.  
 Extensible 150 cm.

Data Cable. RJ45 Connection.  
 Retractable 150 cm.

Câble Informatique. Connexion RJ45.  
 Extensible 150 cm.

Datenkabel. RJ45 Buchse.  
 Erweiterbare 150 cm.

Cavo Dati. Connessione RJ45.  
 Estendibile 150 cm.

Cabo Dados. Conexão RJ45.  
 Extensível 150 cm.

10,5 x 2 x 3,5 cm 400 / 100  
 Print Code: E(4)



### LANDI 3701

Cinta Recogecables. Nylon.

Cord Winder. Nylon.

Range-Cables. Nylon.

Schnur Winder. Nylon.

Cintura Arrotalabile. Nylon.

Fita Recolhe-Cabos. Nylon.

2 x 18 x 0,2 cm 2000 / 100  
 Print Code: D(1)







### HANOI 3434

Cargador USB. 1000 mA.  
 USB Charger. 1000 mA.  
 Chargeur USB. 1000 mA.  
 USB Ladegerät. 1000 mA.  
 Caricatore USB. 1000 mA.  
 Carregador USB. 1000 mA.

2,6 x 2,8 x 2,6 cm 500/50  
 Print Code: F(4)



### KHUM 3433

Cargador Coche USB. 1000 mA.  
 USB Car Charger. 1000 mA.  
 Chargeur Voiture USB. 1000 mA.  
 USB Autoladegerät. 1000 mA.  
 Caricatore Auto USB. 1000 mA.  
 Carregador USB Carro. 1000 mA.

3,2 cm 6 cm 500/50  
 Print Code: F(4)



### ENIO 3748

Cargador. Cargador y Sincronizador.  
 Charger. Charger & Synchronizer.  
 Chargeur. Chargeur et Synchroniseur.  
 Ladegerät. Ladegerät und Sincro.  
 Caricatore. Caricabatteria e Sincronizzatore.  
 Carregador. Carregador e Sincronizador.

9 x 2 x 2,5 cm 200 / 50  
 Print Code: E(4)



### KORUS 3601

Teclado Bluetooth. Compatible con Ipad, Iphone 4G, Google Android y Smartphone Windows Mobile 6.0. Bateria Lito recargable con cable puerto mini USB incluido.

Bluetooth Keyboard. Compatible with iPad, 4G Iphone, Google Android and Windows Mobile 6.0 Smartphone. Rechargeable Lithium Battery with mini USB cable included.

Clavier Bluetooth. Compatible avec iPad, iPhone 4G, Google Android et Smartphone Windows Mobile 6.0. Batterie Lithium Rechargeable Avec Câble. Port mini USB Inclus.


Bluetooth Tastatur. Kompatibel mit iPad, iPhone 4G, Google Android und Windows Mobile 6.0 Smartphone. Lithium-Batterie Wiederaufladbare mit Kabel. Mini USB Port Inklusive.

Tastiera USB. Compatible con iPad, iPhone 4G, Google Android e Smartphone Windows Mobile 6.0. Batteria Lito Ricaricabile con Cavo. Porto mini USB Inclusivo.

Teclado Bluetooth. Compatível com iPad, iPhone 4G, Google Android e Smartphone Windows Mobile 6.0. Bateria Lito Recarregável com Cabo para mini USB Incluído.

11 x 1 x 6,5 cm 80 / 40  
 Print Code: F(4)





### FIVEL 3918

Puntero Láser. Pilas Botón Incluidas.  
 Laser Pointer. Button Batteries Included.  
 Pointeur Laser. Piles Bouton Incluses.  
 Laser Pointer. Knopfzellen Inklusive.  
 Puntatore Laser. Pile Bottone Includa.  
 Punteiro Laser. Pilhas Botão Incluídas.



▮ 1.5 cm 9.7 cm    📦 1000 / 50  
 🔋 Print Code: E(1)



### POLE 9350

Puntero Láser. Pilas Botón Incluidas.  
 Laser Pointer. Button Batteries Included.  
 Pointeur Laser. Piles Bouton Incluses.  
 Laser Pointer. Knopfzellen Inklusive.  
 Puntatore Laser. Pile Bottone Includa.  
 Punteiro Laser. Pilhas Botão Incluídas.

▮ 2.6 x 8.8 x 0.6 cm    📦 500 / 100  
 🔋 Print Code: E(4)



### REPORT 9790

Puntero Láser. Conexión USB.  
 Presentaciones Powerpoint. Botones  
 Avance/ Retroceso.  
 Laser Pointer. USB Connection. Power  
 Point Slideshows. Forward/ Back Buttons.  
 Button Batteries Included.  
 Pointeur Laser. Connexion USB.  
 Présentation Powerpoint. Bouton de  
 Commande.  
 Laser Pointer. USB Anschluss. PowerPoint  
 Präsentationen. Tasten Forward/ Reverse.  
 Puntatore Laser. Connessione USB.  
 Presentazione PowerPoint. Pulsante  
 Avanti/ Dietro.  
 Punteiro Laser. Conexão  
 USB. Apresentações  
 PowerPoint. Botões Avance/ Retrocesso.

▮ 1.5 cm 12 cm    📦 60 / 20  
 🔋 Print Code: F(4)



### RIKKU 4174

Bolígrafo Laser. Pilas Botón Incluidas.  
 Laser Pen. Button Batteries Included.  
 Stylo Laser. Piles Bouton Incluses.  
 Kugelschreiber Laser. Knopfzellen Inklusive.  
 Penna Laser. Pile Bottone Includa.  
 Esferográfica Laser. Pilhas Botão Incluídas.

▮ 1.5 cm 14 cm    📦 500 / 50  
 🔋 Print Code: C(4)





### SUCRE 3478

Lámpara USB. Metálico. 1 Led.  
 USB Lamp. Metallic. 1 Led.  
 Lampe USB. Métallique. 1 Led.  
 USB Lampe. Métallique. 1 Led.  
 Lampada USB. Metallo. 1 Led.  
 Lámpada USB. Metálico. 1 Led.

☰ 0,5 cm 44,5 cm ☰ 200 / 50  
 🔋 🔋 🔋 Print Code: F(4)



### AYLA 3804

Linterna. Recargable USB.  
 Torch. USB Rechargeable.  
 Lampe. Rechargeable USB.  
 Lampe. USB Wiederaufladbar.  
 Torcia. Ricaricabile USB.  
 Lanterna. Recarregável USB.

☰ ø 2 cm 5,5 cm ☰ 400 / 100  
 🔋 🔋 🔋 Print Code: E(1)



### WANYI 3702

Lámpara. Flexible. Pilas Botón Incluidas.  
 Lamp. Flexible. Button Batteries Included.  
 Lampe. Flexible. Piles Bouton Incluses.  
 Lampe. Flexibel. Knopfzellen Inklusive.  
 Lampada. Flessibile. Pila Bottone Includa.  
 Lámpada. Flexível. Pilhas Botão Incluídas.

☰ ø 4 cm 8 cm ☰ 300 / 50  
 🔋 🔋 🔋 Print Code: E(1)



### KONEN 3395

Punto Luz. Pila Botón Incluida.  
 Card Light. Button Battery Included.  
 Point Lumière. Pile Bouton Includa.  
 Leselampe. Knopfzelle Inklusive.  
 Segnalibro Luce. Pila Bottone Includa.  
 Marcador de Livro Luz. Pilha Botão Includa.

☰ 8,7 x 5,4 x 0,4 cm ☰ 800 / 50  
 🔋 🔋 🔋 Print Code: D(4)




01



### LEKTURA 3585

Lámpara Luz. Pilas Botón Incluidas.  
 Light Lamp. Button Batteries Included.  
 Lampe Lumière. Piles Bouton Incluses.  
 Lampe Licht. Knopfzellen Inklusive.  
 Lampada Luce. Pile Bottone Inclusive.  
 Lámpada Luz. Pilhas Botão Incluídas.

25 x 3 x 2 cm 200 / 50  
 Print Code: E(4)



### KYAN 3694

Trípode Universal.  
 Universal Tripod.  
 Trépied Universel.  
 Universal Stativ.  
 Treppiede Universale.  
 Tripé Universal.

∅ 2 cm 12,2 cm 400 / 100  
 Print Code: F(1)



### ELAM 3744

Traductor. 7 Idiomas. Calculadora. Pila Botón Incluida.  
 Traducteur. 7 Langues. Calculatrice. Pile Bouton Inclusive.  
 Übersetzer. 7 Sprachen. Taschenrechner. Knopfzelle Inklusive.  
 Traduttore. 7 Lingue. Calcolatrice. Pila Bottone Inclusive.  
 Tradutor. 7 Idiomas. Calculadora. Pilha Botão Incluída.

11,8 x 1 x 7,2 cm 120 / 60  
 Print Code: F(4)





### WEIS 3733

Set Ordenador. Nylon 1680D.  
4 Accesorios.

Computer Set. Nylon 1680D.  
4 Accessories.

Set Accessoires Ordinateur. Nylon 1680D.  
4 Accessoires.

Computer Zubehör Set. Nylon 1680D.  
4 Teile.

Set Computer. Nylon 1680D. 4 Accessori.

Set Computador. Nylon 1680D.  
4 Acessórios.

13 x 4,5 x 8 cm 80 / 20  
 Print Code: G(6)



### DATA 9787

Set Ordenador. Nylon 420D. 4 Accesorios.  
Computer Set. Nylon 420D. 4 Accessories.

Set Accessoires Ordinateur. Nylon 420D.  
4 Accessoires.

Computer Zubehör Set. Nylon 420D.  
4 Teile.

Set Computer. Nylon 420D. 4 Accessori.

Set Computador. Nylon 420D.  
4 Acessórios.

15,3 x 4,5 x 17,6 cm 40  
 Print Code: G(6)



### GIGA 3045

Funda Porta Ratón. Neopreno.  
Mouse Pouch. Neoprene.

Étui Souris. Néoprène.

Maus Tasche. Neopren.

Custodia Porta-Mouse. Neoprene.

Bolsa Rato. Neopreno.

ø 21 cm 300 / 50  
 Print Code: E(1), N(8)



### READY 9854

PortaCD. 12 CDs.

CD Holder. 12 CDs.

Porte CD. 12 CDs.

CD Case. 12 CDs.

PortaCD. 12 CDs.

Porta-CD. 12 CDs.

15 x 14 x 2 cm 300 / 50  
 Print Code: E(4)





19



19

### KEITA 3547

Ratón. Óptico. Ergonómico.  
 Mouse. Optical. Ergonomic.  
 Souris. Optique. Ergonomique.  
 Maus. Optisch. Ergonomisch.  
 Mouse. Ottico. Ergonomico.  
 Rato. Óptico. Ergonómico.

9.4 x 3.3 x 5.2 cm 100  
 Print Code: F(4)



02



03

### YOIKO 3746

Mini Ratón. Cable Extensible.  
 Mini Mouse. Extendable Cable.  
 Mini Souris. Câble Extensible.  
 Mini Maus. Ausziehbar Kabel.  
 Mini Mouse. Cavo Estendibile.  
 Mini-Rato. Cabo Extensível.

8 x 2 x 3.5 cm 200 / 50  
 Print Code: F(4)



05



02



03



### NEGU 3755

Alfombrilla Teclado. 3 Puertos. USB 2.0.  
 Mousepad Keyboard. 3 Hubs. USB 2.0.  
 Tapis Souris Clavier. 3 Ports. USB 2.0.  
 Mauspad Tastatur. 3 Ports. USB 2.0.  
 Tappetino Mouse Tastiera. 3 Porte. USB 2.0.  
 Tapete Rato Teclado. 3 Portas. USB 2.0.

32 x 21.5 cm 10  
 Print Code: F(1)





■ ■ ANTONIO MIRO ■ ■

### TOPCON 7137

Set Ordenador. Piel. 5 Accesorios.  
 Computer Set. Leather. 5 Accessories.  
 Set Accessoires Ordinateur. Cuir. 5 Accessoires.  
 Computer Zubehör Set. Leder. 5 Teile.  
 Set Computer. Pelle. 5 Accessori.  
 Set Computador. Pele. 5 Acessórios.

16 x 3,6 x 21 cm 20  
 Print Code: G(6), L



### TERA 3734

Set Ordenador. Poliéster 1680D.  
 4 Accesorios.  
 Computer Set. Polyester 1680D.  
 4 Accessories.  
 Set Accessoires Ordinateur. Polyester  
 1680D. 4 Accessoires.  
 Computer Zubehör Set. Polyester 1680D.  
 4 Teile.  
 Set Computer. Poliestere 1680D.  
 4 Accessori.  
 Set Computador. Poliéster 1680D.  
 4 Acessórios.

15,5 x 5 x 21,5 cm 40 / 20  
 Print Code: G(6)



**LOGIK 3966**

Tablet PC. Pantalla 7", Google Android 2.3. Procesador 1.2Ghz. Ram 512MB. Disco 4GB. Cámara. WIFI 802.11 b/g. Puertos Mini USB, TF y HDMI.

Tablette PC. Monitor 7". Google Android 2.3. Processore 1.2 Ghz. Ram de 512MB. Disk de 4GB. Webcam. WIFI 802.11 b/g. Mini Port USB, TF et HDMI.

Tablette PC. Monitor 7". Google Android 2.3. Processore 1.2 Ghz. Ram de 512MB. Disk de 4GB. Webcam. WIFI 802.11 b/g. Mini Port USB, TF et HDMI.

Tablett PC. 7" Screen. Google Android 2.3. Processor 1.2Ghz. Ram 512MB. Festplatten 4GB. Kamera. WIFI 802.11 b/g. Ports Mini USB, TF und HDMI.

Tablet PC. Schermo 7". Google Android 2.3. Processore 1.2 GHz. RAM 512MB. Disk 4GB. Webcam. WIFI 802.11 b/g. Porta Mini USB, TF e HDMI.

Tablet PC. Ecrã 7". Google Android 2.3. Processador 1.2 Ghz. Ram 512MB. Disk 4GB. Webcam. WIFI 802.11 b/g. Portas Mini USB, TF e HDMI.

19 x 12 x 1.5 cm 12 / 6  
Print Code: H(1)



**asiaexpress**  
special designs







### ZOREK 3979

Funda iPad. Soft Shell.  
 iPad Case. Soft Shell.  
 Housse iPad. Soft Shell.  
 iPad Tasche. Soft Shell.  
 Custodia iPad. Soft Shell.  
 Bolsa iPad. Soft Shell.

20 x 25,5 x 1 cm 100 / 50  
 Print Code: F(1), N(6)



### MEGA 3731

Funda iPad. Microfibrá.  
 iPad Case. Microfiber.  
 Housse iPad. Microfibre.  
 iPad Tasche. Mikrofaser.  
 Custodia iPad. Microfibrá.  
 Bolsa iPad. Microfibrá.

23 x 28 x 0,8 cm 100 / 20  
 Print Code: F(1), N(8)



### URAN 3673

Funda iPad. Polipiél.  
 iPad Case. PU.  
 Housse iPad. Similicuir.  
 iPad Tasche. PU.  
 Custodia iPad. PU.  
 Bolsa iPad. PU.

21 x 25,2 x 0,4 cm 100  
 Print Code: F(1), L



### MARLIX 4056

Funda iPad. Poliéster 600D. Acolchado.  
 iPad Case. Polyester 600D. Padded.  
 Housse iPad. Polyester 600D. Matelassé.  
 iPad Tasche. Polyester 600D. Gepolstert.  
 Custodia iPad. Poliestere 600D. Imbottito.  
 Bolsa iPad. Poliéster 600D. Almofadado.

22 x 27 x 6 cm 50 / 10  
 Print Code: F(1), N(8)





### TRADOX 4136

Funda iPad. Polipiel.  
 iPad Case. PU.  
 Housse iPad. Similicuir.  
 iPad Tasche. PU.  
 Custodia iPad. PU.  
 Bolsa iPad. PU.

20,5 x 25 x 2,5 cm 50  
 Print Code: F(1)



### TORA 4180

Funda iPad. Poliéster 600D. Acolchado.  
 iPad Case. Polyester 600D. Padded.  
 Housse iPad. Polyester 600D. Matelassé.  
 iPad Tasche. Polyester 600D. Gepolstert.  
 Custodia iPad. Poliestere 600D. Imbottito.  
 Bolsa iPad. Poliéster 600D. Almofadado.

22 x 27 x 1,5 cm 100  
 Print Code: F(1), N(8)



### YARI 4134

Funda iPad. Polipiel.  
 iPad Case. PU.  
 Housse iPad. Similicuir.  
 iPad Tasche. PU.  
 Custodia iPad. PU.  
 Bolsa iPad. PU.

23 x 26,5 x 2,5 cm 40  
 Print Code: F(1)



### ANTONIO MIRO


#### TAXSA 7168

Funda iPad. Soft Shell.  
 iPad Case. Soft Shell.  
 Housse iPad. Soft Shell.  
 iPad Tasche. Soft Shell.  
 Custodia iPad. Soft Shell.  
 Bolsa iPad. Soft Shell.

27 x 21 x 2 cm 50 / 25  
 Print Code: N(8)



08



### ZORA 3964

Funda iPhone. Silicóna.  
 Iphone Pouch. Silicóna.  
 Housse iPhone. Silicóna.  
 iPhone Tasche. Silikon.  
 Custodia iPhone. Silicóna.  
 Bolsa iPhone. Silicóna.

6 x 11,5 x 1,5 cm 500 / 10  
 Print Code: F(1)



19



### DRIMA 4016

Funda. PVC.  
 Pouch. PVC.  
 Étui. PVC.  
 Hülle. PVC.  
 Custodia. PVC.  
 Estujo. PVC.

8,3 x 13,2 x 0,4 cm 600 / 100  
 Print Code: E(1)



03



### WATERPRO 3042

Portatodo. PVC. Impermeable.  
 Multipurpose Bag. PVC. Waterproof.  
 Pochette. PVC. Imperméable.  
 Mehrzwecktasche. PVC. Wasserdicht.  
 Portaoggetti. PVC. Impermeabile.  
 Bolsa Multiusos. PVC. Impermeável.

9,5 x 23 cm 500 / 50  
 Print Code: E(1)

04



### MOMO 3670

Funda. Microfibra.

Pouch. Microfiber.

Étui. Microfibre.

Hülle. Mikrofaser.

Custodia. Microfibra.

Estojo. Microfibra.

8 x 13,3 x 0,3 cm 1000 / 10

Print Code: F(1), N(8)



### MIM 3732

Funda. Microfibra.

Pouch. Microfiber.

Étui. Microfibre.

Hülle. Mikrofaser.

Custodia. Microfibra.

Estojo. Microfibra.

8,5 x 13,5 x 0,8 cm 500 / 50

Print Code: E(1), N(8)



### YATO 4046

Brazalete. Soft Shell/ PVC. Pantalla Táctil.

Arm Strap. Soft Shell/ PVC. Touch Screen.

Bracelet. Soft Shell/ PVC. Ecran Tactile.

Armband. Soft Shell/ PVC. Touch Screen.

Braccialeto. Soft Shell/ PVC. Touch Screen.

Bracelete. Soft Shell/ PVC. Ecrã Tátil.

7 x 12 cm 200 / 50

Print Code: F(1), N(8)



### AMSTRONG 3635

Brazalete. Poliéster 600D.

Arm Strap. Polyester 600D.

Bracelet. Polyester 600D.

Armband. Polyester 600D.

Braccialeto. Poliestere 600D.

Bracelete. Poliéster 600D.

8 x 12 cm 200

Print Code: E(1), N(8)





03

## TOKI 4151

Soposte Móvil. Superficie Adherente.  
Bolígrafo Puntero Incluido.

Mobile Holder. Sticky Surface. Stylus  
Touch Ball Pen Included.


Support Mobile. Surface Adhésive. Stylet  
Bille Inclus.

Handyhalter. Selbsthaftende Oberfläche.  
Kugelschreiber Pointer Inklusive.

Supporto Cellulare. Superficie Antiscivolo.  
Penna Puntatore Touch Inclusa.

Soposte Telemóvil. Superficie Aderente.  
Inclui Esferográfica Punteiro.

7 x 9,5 x 7 cm 200 / 50  
Print Code: D(4)



08

19



19



03

07

02

## AXEL 3840

Soposte Móvil. Superficie Adherente.

Mobile Holder. Sticky Surface.

Support Mobile. Surface Adhésive.

Handyhalter. Selbsthaftende Oberfläche.

Supporto Cellulare. Superficie Antiscivolo.

Soposte Telemóvil. Superficie Aderente.

6 x 7,5 x 10 cm 250 / 50  
Print Code: D(4)



19

03

02

## FENIX 4020

Soposte Móvil. 5 Piezas. Superficie  
Adherente.

Mobile Holder. 5 Pieces. Sticky Surface.

Support Mobile. 5 Pièces. Surface  
Adhesive.

Handyhalter. 5 Stück. Selbsthaftende  
Oberfläche.

Supporto Cellulare. 5 Pezzi. Superficie  
Antiscivolo.

Soposte Telemóvil. 5 Peças. Superficie  
Aderente.

6 x 9 x 10 cm 200 / 50  
Print Code: D(4)



19



02



01



03



## TOUT 3926

Soposte Limpiapantallas.

Screen Cleaning Holder.

Support Mobile Nettoyier.

Halter Displayreiner.

Supporto Puliscichermo.

Soposte Limpador Ecrã.

4,5 x 3,3 x 4,5 cm 1000 / 100  
Print Code: D(4)





**TEVER 4104**

Soporte Móvil Ajustable.  
Adjustable Mobile Holder.  
Support Mobile Réglable.  
Verstellbarer Handyhalter.  
Supporto Cellulare Regolabile.  
Suporte Telemóvil Ajustável.

6 x 6 cm 7 cm 400 / 100  
Print Code: D(4)



**RUMY 4103**

Soporte.  
Holder.  
Support.  
Halter.  
Supporto.  
Suporte.

3,8 x 4 cm 600 / 100  
Print Code: D(4)



**DALOS 4019**

Soporte.  
Holder.  
Support.  
Halter.  
Supporto.  
Suporte.


6 x 5,5 x 9,5 cm 500 / 50  
Print Code: D(4)



**LAXO 4108**

Soporte Móvil.  
Mobile Holder.  
Support Mobile.  
Handyhalter.  
Supporto Cellulare.  
Suporte Telemóvil.

8 x 2,8 x 8 cm 500 / 100  
Print Code: D(4)






### CORT 3551

Auriculares. Conexión Jack 3,5 mm.  
Headphones. 3,5 mm Jack Socket.  
Écouteurs. Connexion Jack 3,5 mm.  
Kopfhörer. 3,5 mm Klinkestecker.  
Auricolari. Connessione Jack 3,5 mm.  
Auscultadores. Conexão Jack 3,5 mm.

7 x 2 x 7 cm 500 / 50  
 Print Code: F(4)



01



### KEMET 3973

Auriculares. Conexión Jack 3,5 mm.  
Headphones. 3,5 mm Jack Socket.  
Écouteurs. Connexion Jack 3,5 mm.  
Kopfhörer. 3,5 mm Klinkestecker.  
Auricolari. Connessione Jack 3,5 mm.  
Auscultadores. Conexão Jack 3,5 mm.

1,5 x 2,2 x 1,5 cm 500 / 50  
 Print Code: F(4)



### DINO 7029

Auriculares. Conexión Jack 3,5 mm.  
Headphones. 3,5 mm Jack Socket.  
Écouteurs. Connexion Jack 3,5 mm.  
Kopfhörer. 3,5 mm Klinkestecker.  
Auricolari. Connessione Jack 3,5 mm.  
Auscultadores. Conexão Jack 3,5 mm.

ø 4 cm 2 cm 400 / 100  
 Print Code: F(4)




Ideal for sports

### HOOS 7028

Auriculares. Conexión Jack 3,5 mm.  
Headphones. 3,5 mm Jack Socket.  
Écouteurs. Connexion Jack 3,5 mm.  
Kopfhörer. 3,5 mm Klinkestecker.  
Auricolari. Connessione Jack 3,5 mm.  
Auscultadores. Conexão Jack 3,5 mm.

13 x 12 x 1,5 cm 500 / 100  
 Print Code: F(1)





**TABIT 7024**

Auriculares. Conexión Jack 3,5 mm.  
 Headphones. 3,5 mm Jack Socket.  
 Écouteurs. Connexion Jack 3,5 mm.  
 Kopfhörer. 3,5 mm Klinkenstecker.  
 Auricolari. Connessione Jack 3,5 mm.  
 Auscultadores. Conexão Jack 3,5 mm.

15,5 x 21 x 7,5 cm 40 / 20  
 Print Code: F(1)



**ANSER 3974**

Auriculares. Conexión Jack 3,5 mm.  
 Headphones. 3,5 mm Jack Socket.  
 Écouteurs. Connexion Jack 3,5 mm.  
 Kopfhörer. 3,5 mm Klinkenstecker.  
 Auricolari. Connessione Jack 3,5 mm.  
 Auscultadores. Conexão Jack 3,5 mm.

19 x 19 x 9 cm 20  
 Print Code: F(1)



**REM 7027**

Auriculares. Conexión Jack 3,5 mm.  
 Headphones. 3,5 mm Jack Socket.  
 Écouteurs. Connexion Jack 3,5 mm.  
 Kopfhörer. 3,5 mm Klinkenstecker.  
 Auricolari. Connessione Jack 3,5 mm.  
 Auscultadores. Conexão Jack 3,5 mm.

14,8 x 20 x 9 cm 20  
 Print Code: F(1)





### PROBE 3594

Mini Radio. FM Autoscan. Pilas Botón Incluidas.



Mini Radio. FM Autoscan. Button Batteries Included.

Mini Radio. FM Autoscan. Piles Bouton Incluses.

Mini Radio. FM Autoscan. Knopfzellen Inklusive.

Mini-Rádío. FM Autoscan. Pile Bottone Inclusive.

Mini-Rádío. FM Autoscan. Pilhas Botão Incluídas.

 3,7 x 5,5 x 1,6 cm  300 / 150

 Print Code: E(4)



03



19



01



02

### SERI 9351

Mini Radio. FM Autoscan. Pilas Botón Incluidas.

Mini Radio. Autoscan FM. Button Batteries Included.


Mini Radio. FM Autoscan. Piles Bouton Incluses.

Mini Radio. FM Autoscan. Knopfzellen Inklusive.

Mini Radio. FM Autoscan. Pile Bottone Inclusive.

Mini-Rádío. FM Autoscan. Pilhas Botão Incluídas.

 4 x 8 x 1,5 cm  200

 Print Code: E(4)



04



19



03



07

### HIPHOP 3651

Reproductor MP3. Tarjeta MicroSD 4GB y Auriculares Incluidos.

MP3 Player. 4GB MicroSD card and Headphones Included.


Reproducteur MP3. Carte MicroSD 4GB et Casque Inclus.

MP3 Player. 4GB MicroSD Karten und Kopfhörer. Inklusive.

MP3 Player. Carte MicroSD 4GB e Auricolari Inclusive.

Reprodutor MP3. Inclui Cartão MicroSD 4GB e Auscultadores.

 5,8 x 0,8 x 2 cm  100

 Print Code: F(4)



02



03



01



19



### DUPLI 3401

Adaptador. Salida Doble Conexión Jack 3,5 mm.

Adapter. Double Output 3,5 mm Jack Socket.


Adaptateur. Sortie Double Conection Jack 3,5mm.

Adapter. Doppelte Ausgangsanschluss 3,5 mm Klinkenstecker.

Adattatore. Doppia Connessione Jack 3,5 mm.

Adaptador. Saída Doble Conexão Jack 3,5 mm.

1,7 x 16,5 x 1 cm 1000 / 100  
Print Code: D(4)



### KAIL 3705

Recogecables. Magnético.

Cord Winder. Magnetic.


Range-Câbles. Magnétique.

Kabelbinder. Magnetisch.

Avvolgicavo. Magnetico.

Recolhe-Cabos. Magnético.

∅ 4,2 cm 1,2 cm 300 / 50  
Print Code: D(4)



### RIA 3902

Llavero. Aluminio.

Keyring. Aluminium.

Porte-Clés. Aluminium.

Schlüsselanhänger. Aluminium.

Portachiavi. Alluminio.

Porta-Chaves. Alumínio.

2,5 x 6,7 x 0,4 cm 800 / 200  
Print Code: E(4), L





### SUPERBASS 4189

Altavoz. Silicona.

Speaker. Silicone.

Haut-Parleurs. Silikon.


Lautsprecher. Silikon.

Altoparlante. Silicone.

Altifalante. Silicone.

10,6 x 3,7 x 4,5 cm 300 / 10

Print Code: CONSULTAR



### MURMUR 3736

Altavoz. Conexión Jack 3,5 mm.

Speaker. 3,5 mm Jack Socket.

Haut-Parleurs. Connexion Jack 3,5 mm.

Lautsprecher. 3,5 mm Klinkenstecker.

Altoparlante. Connessione Jack 3,5 mm.

Altifalante. Conexão Jack 3,5 mm.

ø 8 cm 80

Print Code: F(4)



### ONIX 3691

Altavoz. Conexión Jack 3,5 mm. Recargable USB.

Speaker. 3,5 mm Jack Socket. USB Rechargeable.

Haut-Parleurs. Connexion Jack 3,5 mm. Rechargeable USB.

Lautsprecher. 3,5 mm Klinkenstecker. USB Wiederaufladbar.

Altoparlante. Connessione Jack 3,5 mm. Ricaricabile USB.

Altifalante. Conexão Jack 3,5 mm. Recarregável USB.

ø 5,2 cm 3,8 cm 200 / 100

Print Code: F(1)



### KUBIC 3742

Altavoz. Reproductor Música. Conexión Jack 3,5 mm. Incluye Cable.

Speaker. Music Player. 3,5 mm Jack Socket. Wire Included.

Haut-Parleurs. Reproducteur Musique. Connexion Jack 3,5 mm. Câble Inclus.

Lautsprecher. Musik Player. 3,5 mm Klinkenstecker. Kabel Inklusive.

Altoparlante. Riprodotto Musicale. Connessione Jack 3,5 mm. Cavo Inclusivo.

Altifalante. Reprodutor de Música. Conexão Jack 3,5 mm. Inclui Cabo.

7,8 x 7,7 x 7,7 cm 50

Print Code: F(4)





03



02

### NIX 3745

Altavoz Soporte Ipad. Conexión Jack 3,5 mm. 4 Pilas AAA/ R03 No Incluidas.

Ipad Holder Speaker. 3,5 mm Jack Socket. 4 Batteries AAA/ R03 Not Included.

Haut-Parleur Support iPad. Connexion Jack 3,5 mm. 4 Piles AAA/ R03 Non Incluses.

iPad Halter Lautsprecher. 3,5 mm Klinkenstecker. 4 AAA/ R03 Batterien Nicht im Lieferumfang.

Alttoparlante Supporto iPad. Connessione Jack 3,5 mm. 4 Batterie AAA/ R03 Non Includo.

Altifalante Base iPad. Conexão Jack 3,5 mm. 4 Pilhas AAA/ R03 Não Incluidas.

21 x 3,2 x 15,5 cm 20  
Print Code: G(2)



19



02



03

### EKO 3497

Altavoz. Conexión Jack 3,5 mm. 3 Pilas AAA/ R03 No Incluidas.

Speaker. 3,5 mm Jack Socket. 3 Batteries AAA/ R03 Not Included.

Haut-Parleurs. Connexion Jack 3,5 mm. 3 Piles AAA/ R03 Non Incluses.

Lautsprecher. 3,5 mm Klinkenstecker. 3 AAA/ R03 Batterien Nicht im Lieferumfang.

Alttoparlante. Connessione Jack 3,5 mm. 3 Batterie AAA/ R03 Non Includo.

Altifalante. Conexão Jack 3,5 mm. 3 Pilhas AAA/ R03 Não Incluidas.

11 x 3,5 cm 80  
Print Code: F(2)



01



### TUNY 3751

Altavoz Radio. Conexión AUX IN y Jack 3,5 mm. 4 Pilas AA/ R06 No Incluidas.

Radio Speaker. Connection AUX IN and 3,5 mm Jack Socket. 4 Batteries AA/ R06 Not Included.

Haut-Parleurs Radio. Connexion AUX IN et Jack 3,5mm. 4 Piles AA/ R06 Non Incluses.

Lautsprecher Radio. AUX IN und 3,5 mm Klinkenstecker. 4 AA/ R06 Batterien Nicht im Lieferumfang.

Alttoparlante Radio. Connessioni AUX IN e Jack 3,5 mm. 4 Batterie AA/ R06 Non Includo.

Altifalante Rádio. Conexão AUX IN e Jack 3,5 mm. 4 Pilhas AA/ R06 Não Incluidas.

9,5 x 16 x 10,5 cm 20 / 10  
Print Code: G(1)



01



03



02



19

02

03



### SCALY 4124

Altavoz Portatodo. Polipiel. Conexión Jack 3,5 mm. Pantalla Táctil. 3 Pilas AAA/ R03 No Incluidas.

Multipurpose Holder Speaker. PU, 3,5 mm Jack Socket. Touch Screen. 3 Batteries AAA/ R03 Non Included.

Haut-Parleurs Pochette. Simili cuir. Connexion Jack 3,5 mm. Ecran Tactile. 3 Piles AAA/ R03 Non Incluses.

Lautsprecher Mehrzwecktasche. PU. 3,5 mm Klinkenstecker. Touch Screen. 3 AAA/ R03 Batterien Nicht im Lieferumfang.

Alttoparlante Portatoggetti. PU. Connessione Jack 3,5 mm. Touch Screen. 3 Batterie AAA/ R03 Non Includo.

Altifalante Portatudo. PU. Conexão Jack 3,5 mm. Ecrã Tátil. 3 Pilhas AAA/ R03 Não Incluidas.

9,5 x 16,5 x 4,5 cm 40  
Print Code: F(4)





## BINTER 3548

Marco Fotos Digital. 1,5". 107 fotos.  
Bateria Recargable. Cable USB Incluido.

Digital Photo Frame. 1,5". 107 photos.  
Rechargeable Battery. USB Cable Included.

Cadre Photos Digitales. 1,5". 107 Photos.  
Batterie Rechargeable. Cable USB Inclus.

Digitaler Fotoramen. 1,5". 107 Foto.  
Wiederaufladbaren Batterie. Kabel USB  
Inklusive.

Cornice Foto Digitale. 1.5". 107 Foto.  
Bateria Ricaricabile. Cavo USB Incluso.

Moldura Fotos Digital. 1,5". 107 fotos.  
Bateria Recarregável. Inclui Cabo USB.

4,5 x 7,8 x 3,9 cm 100 / 20  
Print Code: F(4)



## WELIX 3549

Marco Fotos Digital. 2,4". 78 Fotos.  
Bateria Recargable. Incluye Cable USB.

Digital Photo Frame. 2,4". 78 photos.  
Rechargeable Battery. USB Cable Included.

Cadre Photos Digitales. 2,4". 78 Photos.  
Batterie Rechargeable. Cable USB Inclus.

Digitaler Fotoramen. 2,4". 78 Foto.  
Wiederaufladbaren Batterie. USB Kabel  
Inklusive.

Cornice Foto Digitale. 2.4". 78 Foto.  
Bateria Ricaricabile. Cavo USB Incluso.

Moldura Fotos Digital. 2,4". 78 Fotos.  
Bateria Recarregável. Inclui Cabo USB.

10,5 x 8,5 cm 40  
Print Code: F(2)



01



01



03



02

## LENIX 3970

Reloj. Correa Silicona.

Watch. Silicone Strap.

Montre. Bracelet Silicone.

Uhr. Silikonarmband.

Orologio. Cinturino In Silicone.

Relógio. Bracelete Silicone.

26.5 x 5 x 1.5 cm 200 / 20

Print Code: L





02

### VETUS 3993

Reloj.  
Watch.  
Montre.  
Uhr.  
Orologio.  
Relógio.

25 x 3,8 x 0,8 cm 200 / 20  
Print Code: L



03



19



01



19



03

### SOLTUX 3968

Reloj. Correa Silicona.  
Watch. Silicone Strap.  
Montre. Bracelet Silicone.  
Uhr. Silikonambard.  
Orologio. Cinturino In Silicone.  
Relógio. Bracetele Silicone.

24 x 4,5 x 1,5 cm 200 / 10  
Print Code: G(1), L



02



01



03



02



19

### BALDER 3679

Reloj. Correa Silicona.  
Watch. Silicone Strap.  
Montre. Bracelet Silicone.  
Uhr. Silikonamband.  
Orologio. Cinturino In Silicone.  
Relógio. Bracetele Silicone.

26 x 4,5 x 1,5 cm 200 / 20  
Print Code: L



01



02



19



04



05



07



11

### FOBEX 3678

Reloj. Correa Silicona.  
Watch. Silicone Strap.  
Montre. Bracelet Silicone.  
Uhr. Silikonamband.  
Orologio. Cinturino In Silicone.  
Relógio. Bracetele Silicone.

24,5 x 4 x 1,5 cm 200 / 20  
Print Code: L



03



### TREPID 3588

Reloj. Correa Silicona.  
 Watch. Silicone Strap.  
 Montre. Bracelet Silicone.  
 Uhr. Silikonarmband.  
 Orologio. Cinturino In Silicone.  
 Relógio. Bracelete Silicóna.

25,5 x 4 x 2,5 cm 200 / 50  
 Print Code: F(1)



### KIBOL 3677

Reloj.  
 Watch.  
 Montre.  
 Uhr.  
 Orologio.  
 Relógio.

23,3 x 4 x 0,8 cm 400 / 20  
 Print Code: E(1)



### TOMIUM 3556

Reloj. Talla Unisex.  
 Watch. Unisex Size.  
 Montre. Taille Unisex.  
 Uhr. Unisex.  
 Orologio. Taglia Unisex.  
 Relógio. Tamanho Unisexo.


24 x 4,6 x 2,5 cm 1000 / 100  
 Print Code: F(1)



### LEWIS 9690

Reloj Pulsómetro. Plástico. Calcula Calorías Consumidas. Pilas Botón Incluidas.  
 Watch Pulsometer. Plastic. Calculates Calories Burned. Button Batteries Included.  
 Montre Pulsomètre. Plastique. Calcule Calories Consommées. Piles Bouton Incluses.  
 Pulsuhr. Plastik. Berechnet Verbrannte Kalorien. Knopfzellen Inklusive.  
 Orologio Pulsometro. Plastica. Calcolo Calorie Bruciate. Pile Bottone Incluse.  
 Relógio Pulsómetro. Plástico. Calcula Calorias Consumidas. Pilhas Botão Incluídas.

24 x 4,6 x 2,5 cm 50  
 Print Code: F(1)







19



02



01

### BELEX 3838

Reloj. Correa Silicona.  
 Watch. Silicone Strap.  
 Montre. Bracelet Silicone.  
 Uhr. Silikonarmband.  
 Orologio. Cinturino In Silicone.  
 Relógio. Bracelete Silicone.

24 x 4,5 x 2 cm 200 / 50  
 Print Code: F(1)



03



03



01

### SIREL 3969

Reloj. Correa Silicona.  
 Watch. Silicone Strap.  
 Montre. Bracelet Silicone.  
 Uhr. Silikonarmband.  
 Orologio. Cinturino In Silicone.  
 Relógio. Bracelete Silicone.

41,5 x 2,7 x 0,8 cm 600 / 100  
 Print Code: E(1)



ESPAÑA



ITALIA



PORTUGAL



FRANCIA

### ENKI 3680

Reloj. Correa Silicona.  
 Watch. Silicone Strap.  
 Montre. Bracelet Silicone.  
 Uhr. Silikonarmband.  
 Orologio. Cinturino In Silicone.  
 Relógio. Bracelete Silicone.

26 x 4,9 x 1,3 cm 200 / 20  
 Print Code: L



19



01



03

### SUVA 3589

Reloj.  
 Watch.  
 Montre.  
 Uhr.  
 Orologio.  
 Relógio.

23,2 x 3,2 x 1,7 cm 200 / 50  
 Print Code: E(1)





02



01



### ALMA 7007

Reloj. Correa Silicona.  
 Watch. Silicone Strap.  
 Montre. Bracelet Silicone.  
 Uhr. Silikonarmband.  
 Orologio. Cinturón In Silicone.  
 Relógio. Bracelete Silicone.


8,2 x 5,5 x 8,7 cm 100 / 25  
 Print Code: L



18



02



### YUNAN 7025

Reloj. Correa Silicona.  
 Watch. Silicone Strap.  
 Montre. Bracelet Silicone.  
 Uhr. Silikonarmband.  
 Orologio. Cinturón In Silicone.  
 Relógio. Bracelete Silicone.

8,2 x 5,5 x 8,7 cm 100 / 10  
 Print Code: L



### TOWAR 3905

Caja Reloj.  
 Watch Box.  
 Boîte Montre.  
 Uhrbox.  
 Scatola Orologio.  
 Caixa Relógio.

8,3 x 5,7 x 8,3 cm 200 / 10  
 Print Code: D(1)



**Alexluca**  
 Italy

### BÉRGAMO 9895

Caja Relojes. Polipiel/ Madera.  
 Para 5 Relojes.  
 Watches Box. PU/ Wood.  
 Suitable for 5 Watches.  
 Boîte Montre. Similicuir/ Bois. 5 Montres.  
 Uhrenbox. PU/ Holz. Für 5 Uhren.  
 Scatola Orologi. PU/ Legno.  
 Capacità 5 Orologi.  
 Caixa Relógios. PU/ Madeira.  
 Para 5 Relógios.

29 x 7,5 x 10 cm 12  
 Print Code: G(1), L



## ■■■ ANTONIO MIRO ■■■

## OSIEL 7183

Reloj. Metal/ Polipiel. Movimiento Japonés de Cuarzo. Resistente al Agua 30 m. Correa de Piel. Cristal Mineral.

Watch. Metal/ PU. Japanese Quartz Movement. Water Resistant 30 m. Leather Strap. Mineral Glass.

Montre. Métal/ Similicuir. Mouvement à Quartz Japonais. Etanche 30 m. Bracelet Cuir. Cristal Minéral.

Uhr. Metall/ PU. Japanische Quarzwerk. Wasserdicht 30 m. Lederarmband. Mineralglas.

Orologio. Metallo/ PU. Movimento Giapponese de Cuarzo . Impermeabile 30 m. Cinturino In Pelle. Vetro Minerale.

Relógio. Metal/ PU. Movimento de Quartzo Japonês. Resistente à Água 30 m. Bracetele em Pele. Cristal Mineral.

10 x 6 x 10 cm 100 / 25  
Print Code: L



## ■■■ ANTONIO MIRO ■■■

## ORION 7181

Reloj. Metal/ Polipiel. Movimiento Japonés de Cuarzo. Resistente al Agua 10 m. Correa de Piel. Cristal Mineral.

Watch. Metal/ PU. Japanese Quartz Movement. Water Resistant 10 m. Leather Strap. Mineral Glass.

Montre. Métal/ Similicuir. Mouvement à Quartz Japonais. Etanche 10 m. Bracelet Cuir. Cristal Minéral.

Uhr. Metall/ PU. Japanische Quarzwerk. Wasserdicht 10 m. Lederarmband. Mineralglas.

Orologio. Metallo/ PU. Movimento Giapponese de Cuarzo . Impermeabile 10 m. Cinturino In Pelle. Vetro Minerale.

Relógio. Metal/ PU. Movimento de Quartzo Japonês. Resistente à Água 10 m. Bracetele Em Pele. Cristal Mineral.

10 x 6 x 10 cm 100 / 25  
Print Code: L



## ■■■ ANTONIO MIRO ■■■

## KANOK 7184

Reloj. Metal/ Polipiel. Movimiento Japonés de Cuarzo. Resistente al Agua 30 m. Correa de Piel. Cristal Mineral.

Watch. Metal/ PU. Japanese Quartz Movement. Water Resistant 30 m. Leather Strap. Mineral Glass.

Montre. Métal/ Similicuir. Mouvement à Quartz Japonais. Etanche 30 m. Bracelet Cuir. Cristal Minéral.

Uhr. Metall/ PU. Japanische Quarzwerk. Wasserdicht 30 m. Lederarmband. Mineralglas.

Orologio. Metallo/ PU. Movimento Giapponese de Cuarzo . Impermeabile 30 m. Cinturino In Pelle. Vetro Minerale.

Relógio. Metal/ PU. Movimento de Quartzo Japonês. Resistente à Água 30 m. Bracetele em Pele. Cristal Mineral.

10 x 6 x 10 cm 100 / 25  
Print Code: L



## ■■■ ANTONIO MIRO ■■■

## DIONEL 7182

Reloj. Metal/ Polipiel. Movimiento Japonés de Cuarzo. Resistente al Agua 10 m. Correa de Piel. Cristal Mineral.

Watch. Metal/ PU. Japanese Quartz Movement. Water Resistant 10 m. Leather Strap. Mineral Glass.

Montre. Métal/ Similicuir. Mouvement à Quartz Japonais. Etanche 10 m. Bracelet Cuir. Cristal Minéral.

Uhr. Metall/ PU. Japanische Quarzwerk. Wasserdicht 10 m. Lederarmband. Mineralglas.

Orologio. Metallo/ PU. Movimento Giapponese de Cuarzo . Impermeabile 10 m. Cinturino In Pelle. Vetro Minerale.

Relógio. Metal/ PU. Movimento de Quartzo Japonês. Resistente à Água 10 m. Bracetele em Pele. Cristal Mineral.

10 x 6 x 10 cm 100 / 25  
Print Code: L





PERTEGAZ

### WALTER 7086

Reloj. Correa Piel. Movimiento Japonés de Cuarzo. Resistente al Agua 30 m. Correa de Piel. Cristal Mineral.

Watch. Leather Strap. Japanese Quartz Movement. Water Resistant 30 m. Leather Strap. Mineral Glass.

Montre. Bracelet Cuir. Mouvement à Quartz Japonais. Etanche 30 m. Bracelet Cuir. Cristal Minéral.

Uhr. Lederarmband. Japanische Quarzwerk. Wasserdicht 30 m. Lederarmband. Mineralglas.

Orologio. Cinturino in Pelle. Movimento Giapponese de Quarzo. Impermeabile 30 m. Cinturino In Pelle. Vetro Minerale.

Relógio. Bracelete Pele. Movimento de Quartz Japonês. Resistente à Água 30 m. Bracelete Em Pele. Cristal Mineral.

14 x 5,5 x 10 cm 50  
 Print Code: F(1), L



### BELO 3938

Set Relojes. Metálico.

Watch Set. Metallic.

Set Montres. Métallique.

Uhrenset. Metallic.

Set Orologi. Metallo.

Set Relógios. Metálico.

9,8 x 5,8 x 9,5 cm 50  
 Print Code: L



### KORO 3939

Set Relojes. Metal/ Polipiel.

Watch Set. Metal/ PU.

Set Montres. Métal/ Similicuir.

Uhrenset. Metal/ PU.

Set Orologi. Metallo/ PU.

Set Relógios. Metal/ PU.

9,8 x 5,8 x 9,5 cm 50  
 Print Code: L



### ROCHE 9600

Set Relojes. Metálico.

Watch Set. Metallic.

Set Montres. Métallique.

Uhrenset. Metallic.

Set Orologi. Metallo.

Set Relógios. Metálico.

11,5 x 6,5 x 10,5 cm 50  
 Print Code: L



## DHARMA 3262

Estación Meteorológica. Retroiluminada.  
2 Pilas AAA/ R03 No Incluidas.

Weather Station. Backlight. 2 Batteries  
AAA/ R03 Not Included.

Station Météo. Retro-illuminé.  
2 Piles AAA/ R03 Non Incluses.

Wetterstation. Hintergrundbeleuchtung.  
2 AAA/ R03 Batterien Nicht im Lieferumfang.

Stazione Meteorologica. Retroilluminata.  
2 Batterie AAA/ R03 Non Includere.

Estação Meteorológica. Retroluminação.  
2 Pilhas AAA/ R03 Não Incluidas.

 12 x 8,5 x 4 cm  20  
 Print Code: G(4)



## ORCHID 3263

Estación Meteorológica. Retroiluminada.  
2 Pilas AAA/ R03 No Incluidas.

Weather Station. Backlight. 2 Batteries  
AAA/ R03 Not Included.

Station Météo. Retro-illuminé. 2 Piles AAA/  
R03 Non Incluses.

Wetterstation. Hintergrundbeleuchtung.  
2 AAA/ R03 Batterien Nicht im Lieferumfang.

Stazione Meteorologica. Retroilluminata.  
2 Batterie AAA/ R03 Non Includere.

Estação Meteorológica. Retroluminação.  
2 Pilhas AAA/ R03 Não Incluidas.

 7,5 x 14,5 x 4,2 cm  50  
 Print Code: G(4)





02

### ETNA 3740

Estación Meteorológica. Pila Botón Incluida.

Weather Station. Button Batteries Included.

Station Météo. Pile Bouton Incluse.

Wetterstation. Knopfzelle Inklusive.

Stazione Meteorologica. Pila Bottone Inclusa.

Estação Metereológica. Pilha Botão Incluída.

7 x 11 x 1,3 cm 100 / 20  
 Print Code: G(4)



19

### CERES 3739

Estación Meteorológica. Sensor Temperatura Interior/ Exterior. 2 Pilas AAA/ R03 No Incluidas.

Weather Station. Indoor/ Outdoor Temperature Sensor. 2 Batteries AAA/ R03 Not Included.

Station Météo. Capteur Température Intérieure/ Extérieure. 2 Piles AAA/ R03 Non Incluses.

Wetterstation. Innentemperatur Sensor. 2 AAA/ R03 Batterien Nicht im Lieferumfang.

Stazione Meteorologica. Sensore Temperatura Interna/ Esterna. 2 Batterie AAA/ R03 Non Inclusive.

Estação Metereológica. Sensor Temperatura Interior/ Exterior. 2 Pilhas AAA/ R03 Não Incluidas.

11,6 x 13,5 x 4 cm 50  
 Print Code: G(4)



### POLTER 3830

Termómetro. Pila Botón Incluida.

Thermometer. Button Batteries Included.

Thermomètre. Pile Bouton Incluse.

Thermometer. Knopfzelle Inklusive.

Termometro. Pila Bottone Inclusa.

Termómetro. Pilha Botão Incluída.

9 x 10 x 2,8 cm 150 / 50  
 Print Code: E(4)



01

### KLAMEN 4029

Termómetro. 1 Pila AAA/ R03 No Incluida.

Thermometer. 1 Battery AAA/ R03 Not Included.

Thermomètre. 1 Pile AAA/ R03 Non Inclusive.

Thermometer. 1 AAA/ R03 Batterie Nicht im Lieferumfang.

Termometro. 1 Batterie AAA/ R03 Non Inclusive.

Termómetro. 1 Pilha AAA/ R03 Não Incluida.

8 x 13,5 x 3 cm 80 / 20  
 Print Code: E(4)



04



05

03

**NAIN 9338**

Sudoku. 2 Pilas AAA/ R03 No Incluídas.

Sudoku. 2 Batteries AAA/ R03 Not Included.


Sudoku. 2 Piles AAA/ R03 Non Includes.

Sudoku. 2 AAA/ R03 Batterien Nicht im Lieferumfang.

Sudoku. 2 Batterie AAA/ R03 Non Include.

Sudoku. 2 Pilhas AAA/ R03 Não Incluídas.

 8,5 x 13 x 2 cm  100

 Print Code: F(4)

**AA/ R06 2308**

Blisters 4 Pilas 1,5V.

4 Batteries Pack 1,5V.


Blisters 4 Piles 1,5V.

Blisters 4 Batterien 1,5V.

Blisters 4 Batterie 1,5V.

Blisters 4 Pilhas 1,5V.

 8,5 x 11,5 x 1,6 cm  960 / 12

 Print Code:

**AAA/ R03 2309**

Blisters 4 Pilas 1,5V.

4 Batteries Pack 1,5V.


Blisters 4 Piles 1,5V.

Blisters 4 Batterien 1,5V.

Blisters 4 Batterie 1,5V.

Blisters 4 Pilhas 1,5V.




 8,4 x 11,4 x 1,2 cm  1200 / 12

 Print Code:



**THAMES 3276**

Reloj. Funciona Con Agua.  
 Desk Clock. Water Powered.  
 Horloge. Fonctionne Avec de l'Eau.  
 Tischuhr. Funktioniert mit Wasser.  
 Orologio. Funzionamento Ad Acqua.  
 Relógio. Funciona com Água.

 8,6 x 8,5 x 6,5 cm  60 / 30  
 Print Code: G(4)



03




19



04

**SFERA 3232**

Reloj.  
 Desk Clock.  
 Horloge.  
 Tischuhr.  
 Orologio.  
 Relógio.

 5,5 x 8,8 x 2,5 cm  200 / 50  
 Print Code: F(4)



02



19



03



01

**PROTER 3457**

Reloj. Aluminio. 1 Pila AA/ R06 No Incluida.  
 Desk Clock. Aluminium. 1 Battery AA/ R06 Not Included.

Horloge. Aluminium. 1 Pile AA/ R06 Non Incluse.

Tischuhr. Aluminium. 1 AA/ R06 Batterien Nicht im Lieferumfang.

Orologio. Alluminio. 1 Batteria AA/ R06 Non Inclusa.

Relógio. Alumínio. 1 Pilha AA/ R06 Não Incluída.

 ø 8,8 cm 5,2 cm  80 / 20  
 Print Code: F(1)



19

02

03





02



07



19



03

### TECHNIS 9595

Reloj. 1 Pila AA/ R06 No Incluida.

Wall Clock. 1 Battery AA/ R06 Not Included.

Pendule. 1 Pile AA/ R06 Non Inclusive.

Wanduhr. 1 AA/ R06 Batterien Nicht im Lieferumfang.

Orologio. 1 Batteria AA/ R06 Non Inclusa.

Relógio. 1 Pilha AA/ R06 Não Incluída.

21,8 x 30 x 3,9 cm 10

Print Code: G(1)



19

### PREGO 9301

Reloj. 1 Pila AA/ R06 No Incluida.

Wall Clock. 1 Battery AA/ R06 Not Included.

Pendule. 1 Pile AA/ R06 Non Inclusive.

Wanduhr. 1 AA/ R06 Batterien Nicht im Lieferumfang.

Orologio. 1 Batteria AA/ R06 Non Inclusa.

Relógio. 1 Pilha AA/ R06 Não Incluída.

ø 32 cm 2,2 cm 10

Print Code: G(1)



03



02



01



02



03



19

### CRONOS 3676

Reloj. 1 Pila AA/ R06 No Incluida.

Wall Clock. 1 Battery AA/ R06 Not Included.

Pendule. 1 Pile AA/ R06 Non Inclusive.

Wanduhr. 1 AA/ R06 Batterie Nicht im Lieferumfang.

Orologio. 1 Batteria AA/ R06 Non Inclusa.

Relógio. 1 Pilha AA/ R06 Não Incluída.

▣ 29,8 cm 4 cm 20  
 Print Code: F(1)



19



02



03

### VIK 3458

Reloj. 1 Pila AA/ R06 No Incluida.

Wall Clock. 1 Battery AA/ R06 Not Included.

Pendule. 1 Pile AA/ R06 Non Inclusive.

Wanduhr. 1 AA/ R06 Batterien Nicht im Lieferumfang.

Orologio. 1 Batteria AA/ R06 Non Inclusa.

Relógio. 1 Pilha AA/ R06 Não Incluída.

▣ 19,5 x 33,5 x 4 cm 20  
 Print Code: G(1)